

AQUAWORX COLLECTOR TANK INSTALL AND OPERATION GUIDE



Aquaworx collector tanks are manufactured for the purpose of not allowing direct suction from the mains and gutters on swimming pools and spas. The following is a basic installation guide and operating manual for Aquaworx collector tanks.

Installation:

- The collector tank must be set on a level set of concrete or pavers.
- The collector tank must be plumbed to all state and local codes.
- The static water level should be 8" from the top of the collector tank.
- When backfilling the tank after it has been plumbed it must be filled with water at the same time. This will insure that the tank is set properly.

Operating procedures and water level control

- Once the collector tank has been set and the pool is ready for plaster the tank may be used to flush the lines if there are valves in the tank. Close the two valves (pool) or one valve (spa) if required. Fill the tank with clean fresh water to the desired level. Then you may open the valves and flush the lines.
- **Never operate the valves when the pumps are running.**
- These valves may be set at different positions to allow for different flow rates between the main and the gutters.
- The float part of the autofill must be glued into the port that is being used as the static line.
- We provide two open ports and one is used for the static and the other is for the overflow.
- If there is no overflow you may cap the extra 2" port.
- Once the pool is filled to the desired operating level you may set the float at the level of the water with the pump or pumps not running.

Aquaworx Inc.

Limited Warranty

Aquaworx Inc. warrants this product against defects in material or workmanship as follows:

One Year warranty on all parts and materials manufactured by Aquaworx Inc. commencing on the date of purchase. This to include all components that were on the original signed sales order.

This warranty does not include and does not extend to any of the following:

(a) Component failure caused by normal wear and tear, climatic conditions, misuse, neglect, lack of proper maintenance, accident, fire or other casualty damage, negligence, or modification without manufactures written approval. (b) Fading, chalking, MILK or cosmetic cracking of any kind. Cost of removal or reinstallation of any component or the product itself.

Storage of any kind of chemical inside an AquaWorx cabinet will void this warranty for all components housed inside the cabinet as well as the cabinet.

Limitations: The repair or replacement of defective parts shall be purchaser's sole and exclusive remedy and Aquaworx Inc. sole and exclusive liability under this warranty. Aquaworx obligation under this warranty is limited to the repair or replacement of any covered item found to be defective. Repair or replacement items are warranted as provided herein for the unexpired portion of the applicable warranty period.

This warranty and the rights and remedies under it, is exclusive and is given in place of all other warranties, whether express or implied, including and implied warranty of merchantability or fitness for a particular purpose. Purchaser's remedies shall be limited as stated herein and Aquaworx shall not be liable for any incidental, consequential or indirect damages or losses resulting from defects.

The selling dealer is not a co-warrantor and is not authorized by Aquaworx Inc. to amend or modify this Limited warranty in any manner.



P.O. BOX 66284 ST.
PETERSBURG, FL. 33706
727 329 8845

REVISIONS	AT 125		DWG #	
DESIGNS 3 2/018	TITLE MECHANICAL LAYOUT		SHEET 1 of 1	
JCE 2/019	160 GALLON TANK		REV. DATE	
XXX 1/06	DATE 02.20.2014	PLOT SCALE NONE	PWN X	
XXXX 2/003	SCALE 3/8" = 1'-0"	REV	DRN BY	DATE
FRACTIONS ±1/32	DWN BY JVW	REV-		APPRD DATE
ANGLES ±1/2°	APPROVED			

